

USER MANUAL FORTE 38.093.10

Specifications:

Chip-set: JL6956
Bluetooth version: 5.4
Speaker: 2*15W
Battery: 3.7V/6000 mAh
Bluetooth work distance: 10 m
Waterproof: IPX7
Charging time: 4hrs
Play time: 100% volume up to 7 hours
70% volume up to 25 hours
Material: ABS+Fabric
Frequency response: 120HZ-20KHZ
Horn size: 78 mm 42 mm
Size: 313*125.5*119 mm
Product weight: 2.5 Kg
Charging port: Type C
Case: Rubber Paint
Functions: BT, USB, TF, AUX, Call, Light

Model: FORTE
Pairing name: Forte

It is recommended to read this user manual carefully and keep it for future reference

Buttons & Slots



Button	Function	Operation
Power button	Power on/off	Press 1.5 seconds
	Force restart	Long press for 8 seconds to force restart
Music & Volume	Volume up	Short press
	Next song	Long press 1.5 seconds
Music & Volume	Volume down	Short press
	Previous song	Long press 1.5 seconds
Pause Phone Call	Play/pause	Short press
	Answer/end phone call	Short press to answer During call: short press to end a call
	Reject a call	Incoming call: long press 1.5 seconds to reject
	Voice assistant	Under BT mode, long press 1.5 seconds
	Redial last number	Under BT mode: press 2 times

Button	Function	Operation
Mode button	Mode switch	Short press: BT - AUX - USB - TF
	Disconnect Bluetooth	Long press 2 seconds
	Clear Bluetooth pairing information	Long press 5 seconds
Light button	Enter/exit TWS mode	Double press
	Light control	Short press to turn on/off/switch light mode

KORISNIČKO UPUTSTVO FORTE 38.093.10

Specifikacije:

Čip-set: JL6956
Bluetooth verzija: 5.4
Zvučnik: 2*15W
Baterija: 3.7V/6000 mAh
Radna distanca: 10 m
Vodootpornost: IPX7
Vreme punjenja: 4 sata
Vreme reprodukcije: 100% jačina zvuka do 7 sati
70% jačina zvuka do 25 sati
Materijal: ABS+Tkanina
Frekvencijski odziv: 120HZ-20KHZ
Veličina zvučnika: 78 mm 42 mm
Dimenzije: 313*125.5*119 mm
Težina proizvoda: 2.5 Kg
Port za punjenje: Type C
Poklopac: Gumirani premaz
Funkcije: BT, USB, TF, AUX, Poziv, Svetlo

Model: FORTE
Ime za povezivanje: Forte

Preporučuje se da pažljivo pročitate ovaj korisnički priručnik i sačuvate ga za buduću upotrebu.

Komande i ulazi



Dugme	Funkcija	Operacija
Dugme za uključivanje	Uključivanje/Isključivanje	Pritisnite 1.5 sekundu
	Prisilan restart	Držite pritisnuto 8 sekundi za prisilan restart
Muzika i zvuk	Povećanje jačine zvuka	Kratak pritisak
	Sledeća pesma	Držite pritisnuto 1.5 sekundu
Muzika i zvuk	Smanjenje jačine zvuka	Kratak pritisak
	Prethodna pesma	Držite pritisnuto 1.5 sekundu
Pauza Telefonski poziv	Pusti/Pauziraj	Kratak pritisak
	Odgovori/Kraj telefonskog poziva	Kratak pritisak za odgovor Kratak pritisak za kraj poziva
	Odbijanje poziva	Dolazeći poziv: držite pritisnuto 1.5 sekundu da biste odbili poziv
	Glasovni asistent	U BT režimu, držite pritisnuto 1.5 sekundu
	Ponovno biranje poslednjeg broja	U BT režimu: pritisnite 2 puta

Dugme	Funkcija	Operacija
Taster za režim	Prekidač režima	Kratak pritisak: BT - AUX - USB - TF
	Prekini Bluetooth povezivanje	Držite pritisnuto 2 sekunde
	Obrisi Bluetooth informacije	Držite pritisnuto 5 sekundu
Taster za svetlo	Uđi/izadi iz TWS režima	Dupli pritisak
	Kontrola svetla	Kratak pritisak za uključivanje/isključivanje/promenu režima svetla