

LENNON WIRELESS HEADSET

1. ☪

Long press for 3 seconds to switch the machine, short press to play or pause When there is an incoming call, short press to answer the call Long press to reject Double click to call back the last number

2. -

When in wireless mode, short press to select the previous song. Long press to decrease volume.

3. +

When in wireless mode, short press to select the next song. Long press to increase volume.

4. M

Long press for 3 seconds power on/ power off is ANC ON/ ANC OFF. Green light ON/OFF.

Indicator light:

Wireless mode: red and blue light flash in pairing mode, and blue light flash slowly after successful pairing. Charging

mode: the red light will be on long when charging, and the red light will be off after charging.

ANC mode: When ANC on, the green light keep lighting steadily, when ANC off, the green light turn off

Wireless Operation Instructions:

Press the ☪ key to power on.

Red and blue light flash, product enter into the pairing mode.

Search this wireless product with mobile phone, product BT name is LENNON

When the phone searches for LENNON device name and connect.

When the wireless connection is successful, the blue light flashes slowly.

Open the mobile phone music player to play music, the product can control the wireless music up and down, play pause and call answer, redial and other functions.

LINE External Audio Input Operation Instructions:

When the product is powering on, insert the audio cable into AUXLINEIN mode. Support mobile phone /MP4/ MP3/CD/ laptop and other external audio input.

Functional parameters:

USB charging: DC 5V / 1A IN

Wireless frequency: 2.402-2.480 GHz

Wireless distance: 10 m

Frequency response: 20 HZ-20 khz

Signal to noise ratio: 88 DB

Charging time: 4 hours

Remarks: If the headset cannot be turned on, please charge the headset before use

LENNON BEŽIČNE SLUŠALICE

1. 

Dugim pritiskom (3 sekunde) uključujete/isključujete uređaj. Kratkim pritiskom pauzirate ili puštate muziku. Kod dolaznog poziva, kratko pritisnite da odgovorite. Dugim pritiskom odbijate poziv. Dvostrukim klikom pozivate poslednji broj.

2. -

U bežičnom režimu, kratkim pritiskom birate prethodnu pesmu. Dugim pritiskom smanjujete jačinu zvuka.

3. +

U bežičnom režimu, kratkim pritiskom birate narednu pesmu. Dugim pritiskom povećavate jačinu zvuka.


4. M

Dugim pritiskom (3 sekunde) uključujete/isključujete uređaj, kao i ANC (aktivno poništavanje buke). Zelena lampica se pali/gasi kada je ANC uključen/isključen.

Indikatorska lampica:

Bežični režim: crvena i plava lampica trepću u režimu uparivanja; nakon uspešnog uparivanja, plava lampica trepće sporo. Režim punjenja: crvena lampica svetli neprekidno tokom punjenja; gasi se kada je punjenje završeno. ANC režim: kada je ANC uključen, zelena lampica stalno svetli; kada je isključen, zelena lampica se gasi.

Uputstvo za bežični rad:

Pritisnite dugme  da uključite uređaj. Crvena i plava lampica trepću — uređaj ulazi u režim uparivanja. Pretraživanjem na telefonu pronađite bežični uređaj imena LENNON i povežite se.

Kada je bežična veza uspešno uspostavljena, plava lampica trepće sporo. Otvorite muzički plejer na telefonu i puštajte muziku. Uređaj podržava sledeće funkcije: puštanje/pauza, preskakanje pesama, odgovaranje na pozive, ponovno pozivanje poslednjeg broja.

Uputstvo za spoljni audio ulaz (LINE IN):

Kada je uređaj uključen, priključite audio kabl u režim AUX LINE IN. Podržava spoljni ulaz sa mobilnog telefona, MP4/MP3 plejera, CD plejera, laptopa i sl.

Funkcionalni parametri:

USB punjenje: DC 5V / 1A

Bežična frekvencija: 2,402 – 2,480 GHz

Domet bežične veze: 10 metara

Frekventni opseg: 20 Hz – 20 kHz

Odnos signal/šum: 88 dB

Vreme punjenja: 4 sata