

MORRISON WIRELESS HEADSET

1. II◀

Long press for 3 seconds to switch the machine, short press to play or pause When there is an incoming call, short press to answer the call Long press to reject Double click to call back the last number

2. I◀

When in wireless mode, short press to select the previous song. Long press to decrease volume.

3. ▶I

When in wireless mode, short press to select the next song. Long press to increase volume.

4. M

Long press to disconnect or connect the bluetooth.

Indicator light:

Wireless mode: red and blue light flash in pairing mode, and blue light flash slowly after successful pairing. Charging mode: the red light will be on long when charging, and the red light will be off after charging.

Wireless Operation Instructions:

Press the II◀ key to power on.

Red and blue light flash, product enter into the pairing mode.

Search this wireless product with mobile phone, product BT name is MORRISON When the phone searches for MORRISON device name and connect. When the wireless connection is successful, the blue light flashes slowly. Open the mobile phone music player to play music, the product can control the wireless music up and down, play pause and call answer, redial and other functions.

LINE External Audio Input Operation Instructions:

When the product is powering on, insert the audio cable into AUXLINEIN mode. Support mobile phone /MP4/ MP3/CD/ laptop and other external audio input.

Functional parameters:

USB charging: DC 5V /1A IN

Wireless frequency: 2.402-2.480 GHz

Wireless distance: 10 m

Frequency response: 20 HZ-20 khz

Signal to noise ratio: 88 DB

Charging time: 2 hours

MORRISON BEŽIČNE SLUŠALICE

1. II◀

Dug pritisak (3 sekunde) za uključivanje/isključivanje uređaja. Kratak pritisak za puštanje ili pauziranje muzike. Kada stigne poziv, kratkim pritiskom se javlja na poziv. Dugim pritiskom se odbija poziv. Dvostrukim klikom se poziva poslednji birani broj.

2. I◀

U bežičnom režimu, kratkim pritiskom se bira prethodna pesma. Dugim pritiskom se smanjuje jačina zvuka.

3. ▶I

U bežičnom režimu, kratkim pritiskom se bira sledeća pesma. Dugim pritiskom se povećava jačina zvuka.

4. M

Dugim pritiskom se povezuje ili prekida Bluetooth veza.

Indikatorska lampica:

Bežični režim: crveno-plavo svetlo treperi u režimu uparivanja, plavo svetlo treperi sporo kada je povezivanje uspešno.

Režim punjenja: crveno svetlo stalno svetli dok se puni, a gasi se kada je punjenje završeno

Uputstvo za rad u bežičnom režimu:

Pritisnite taster II◀ za uključivanje uređaja. Crveno i plavo svetlo trepere — uređaj je u režimu uparivanja.

Na mobilnom telefonu potražite bežični uređaj pod imenom MORRISON. Kada se uspostavi bežična veza, plavo svetlo počinje sporo da treperi. Otvorite muzički plejer na telefonu da pustite muziku. Uređaj može da kontroliše muziku: sledeća/prethodna pesma, pauza/puštanje, javljanje/ponovno pozivanje.

Uputstvo za LINE eksterni audio ulaz:

Kada je uređaj uključen, priključite audio kabl u AUX/LINE IN priključak. Podržava eksterni audio ulaz sa mobilnog telefona, MP4/MP3 plejera, CD plejera, laptopa i drugih uređaja.

Funkcionalni parametri:

USB punjenje: DC 5V / 1A

Bežična frekvencija: 2.402–2.480 GHz

Bežična udaljenost: 10 m

Frekventni opseg: 20 Hz – 20 kHz

Odnos signal/šum: 88 dB

Vreme punjenja: 2 sata