

USER MANUAL

TIMEOUT 30.076.90

FUNCTIONS:

Display format - 12/24H

Alarm function

Indoor temperature range: 0°C ~ 50°C

LED backlight

Power consumption: 2 x AAA batteries (excluded)



TIME SETTING:

Hold the SET button to enter the time setting mode.

The setting sequence is Hour -> Minute -> Year -> Month -> Date -> Day.

During the setting process, press the UP/DOWN button to increase or decrease the value.

The setting will be confirmed and exited without any operation in 30 seconds.

ALARM SETTING:

Hold the ALARM button once to turn the alarm on or off. If the alarm is on, a bell icon will be displayed on the screen.

Hold the ALARM button to enter the alarm setting mode.

The setting sequence is Hour -> Minute.

Press the UP button to increase or the DOWN button to decrease the value.

When the alarm rings, press any button except SNOOZE to turn it off.

If you want to snooze the alarm, press the SNOOZE button to set the snooze time.

TEMPERATURE DISPLAY FORMAT:

Press WAVE key to switch temperature mode to °C or °F.

LED BACKLIGHT:

Press SNOOZE/LIGHT button to lit up the screen for 5 seconds.

UPUTSTVO ZA UPOTREBU

TIMEOUT 30.076.90

FUNKCIJE:

Format prikaza – 12/24H

Funkcija alarma

Opseg unutrašnje temperature: 0°C ~ 50°C

Led pozadinsko osvetljenje

Potrošnja energije: 2 x AAA baterije (nisu uključene)



PODEŠAVANJE VREMENA:

Držite taster SET kako biste ušli u režim podešavanja vremena.

Sekvenca podešavanja je Sat -> Minut -> Godina -> Mesec -> Datum-> Dan

Tokom procesa podešavanja pritisnite taster UP/DOWN da biste povećali ili smanjili vrednost.

Podešavanje će biti potvrđeno i izlazak će se izvršiti ako ne bude bilo kakve operacije nakon 30 sekundi.

PODEŠAVANJE ALARMA:

Pritisnite taster ALARM jednom da biste uključili ili isključili alarm. Ako je alarm uključen na ekranu će se prikazivati ikona zvona.

Držite taster ALARM kako biste ušli u režim podešavanja alarma.

Sekvenca podešavanja je Sat -> Minut

Dodirnite taster UP za povećanje ili taster DOWN za smanjenje vrednosti.

Kada alarm zazvoni, pritisnite bilo koje dugme osim SNOOZE da biste ga isključili.

Ukoliko želite da odložite alarm, pritisnite dugme SNOOZE da biste podesili vreme odlaganja.

FORMAT PRIKAZA TEMPERATURE:

Pritisnite taster WAVE da biste prebacili prikaz temperature u °C ili °F.

LED POZADINSKO OSVETLJENJE:

Pritisnite dugme SNOOZE/LIGHT da biste osvetili ekran na 5 sekundi.