

USER MANUAL

AM/FM/SW 3 band radio with bluetooth

RETRO TUNE
38.102

PRECAUTIONS

To maintain good performance, do not put the unit in places which are extremely hot, cold, dusty or humid, specially do not keep the unit:

1. In a high humidity area.
2. Near a heater.
3. In an area exposed to direct sunlight.

WARNING

1. For the non-professional personnel, please do not open the case of the product and touch the inner part.
2. This product uses direct current, therefore please disconnect the unit first when you want to do some maintenance.
3. Disconnect the unit if it is unused for a long time.
4. Never connect the unit when hands are wet.

REGULAR MAINTENANCE

Inner maintenance

Use a cotton swab lightly moistened with cleaning liquid or denatured alcohol.

When the parts are cleaned let it dry before using the unit.

Outside maintenance

1. When the case becomes dirty or stained, use a soft cloth lightly moistened with a mild detergent and wipe clean. Do not use strong solvents (alcohol, benzine, thinner, etc.) to clean the case, do not use dry towel to scrape the case.
2. Keep the plug of headphones away from magnetic goods.

RADIO OPERATION

1. Choose bands: tune band switch, can choose AM, FM, SW.
2. Turn the "TUNING" button to choose the required station.
3. Adjust antenna position to get the best receiving effect.

NOTICE BEFORE USING

1. Put product in the well-ventilated place, and let all its sides (such as surrounding, back or top) have at least 10CM as free space.
2. Avoid cleaning with oil, chemical solvent, or insecticide.
3. When using product, please avoid abnormal temperature, moist water droplet, prevent using under high temperature (above 60) or very low temperature.
4. Keep away from the direct sunlight, strong magnetic field, extreme dirty or wet place (aswell as computer, fax machine etc.) to prevent electrical interference from such equipment.

BLUETOOTH CONNECTION

Turn on the radio and switch the band switch button to "MUSIC", will sound "waiting for pairing", then use your phone to find the Bluetooth name of the device (RETRO TUNE) and connect it.

FUNCTION

1. DC Jack
2. USB Slot
3. TF Slot
4. Band Selection Button
5. Antenna
6. Handle
7. Turning Knob
8. Volume button
9. Prev
10. Play/Pause
11. Next
12. Mode



SPECIFICATION

General specification

Voltage: DC: 5V1A
Output power: 3.8W
Speaker: 5W 4Ω 57mm
Receiving frequency:
FM: 87.5-108MHZ AM: 522-1620KHZ SW: 5.6-22 MHZ
Rechargeable battery: 3.7V 1200mAh 4.44Wh Li-ion battery

How to use rechargeable battery?

1. The unit removable Li-ion battery rechargeable battery, please note that first time need to charge 3-4hours.
2. Normally, if use rechargeable battery, it can Operate unit in following time:
If use for USB/TF/BT --- about 4 hours
If use for radio --- about 5.5 hours



WARNING:

Keep away from heat and fire. Don't put under strong sunshine. Please use to confirm the safe stipulation batter charge, don't charge while using. Do not remove cover (or back), no user serviceable parts inside. Refer servicing to qualified service personnel.

KORISNIČKO UPUTSTVO

AM/FM/SW 3-opsežni radio sa bluetooth-om

RETRO TUNE
38.102

PAŽNJA

Da biste održali dobar rad, nemojte stavljati uređaj na mesta koja su ekstremno vruća, hladna, prašnjava ili vlažna, posebno nemojte držati uređaj:

1. Na području sa visokom vlagom,
2. U blizini grejača.
3. Na mestu izloženom direktnoj sunčevoj svetlosti.

UPOZORENJE

1. Za neprofesionalno osoblje, nemojte otvarati kućište proizvoda niti dodirivati unutrašnje delove.
2. Ovaj proizvod koristi istosmernu struju, stoga prvo isključite uređaj pre nego što izvršite bilo kakvo održavanje.
3. Isključite uređaj ako se neće koristiti duži vremenski period.
4. Nikada ne povezujte uređaj sa vlažnim rukama.

REDOVNO ODRŽAVANJE

Unutrašnje održavanje

Koristite pamučni štapić koji je lagano navlažen tečnošću za čišćenje ili denaturisanim alkoholom.

Nakon čišćenja, ostavite delove da se osuše pre nego što ponovo koristite uređaj.

Spoljno održavanje

1. Kada kućište postane prljavo ili zaprljano, koristite meku krpu koja je lagano navlažena blagim deterdžentom i obrišite. Nemojte koristiti jake rastvarače (alkohol, benzin, razređivač, itd.) za čišćenje kućišta, nemojte koristiti suhu krpu za brisanje kućišta.
2. Držite priključak za slušalice dalje od magnetskih predmeta.

RADIO FUNKCIJA

1. Izbor opsega: pomoću dugmeta možete birati AM, FM, SW.
2. Okrenite dugme za "TUNING" da biste odabrali željenu stanicu.
3. Podesite poziciju antene kako biste dobili najbolji prijem.

OBAVEŠTENJE PRE KORIŠĆENJA

1. Stavite proizvod na dobro provetreno mesto, i obezbedite da sa svih strana (kao što su okolina, zadnja ili gornja strana) ima barem 10 cm slobodnog prostora.
2. Izbegavajte čišćenje proizvoda sa uljem, hemijskim rastvaračima ili insekticidima.
3. Pri korišćenju proizvoda, izbegavajte abnormalne temperature, kapljice vlage, kao i korišćenje na visokim temperaturama (iznad 60°C) ili vrlo niskim temperaturama.
4. Držite uređaj daleko od direktne sunčeve svetlosti, jakih magnetnih polja, veoma prljavih ili vlažnih mesta (kao što su računari, faks mašine itd.) kako biste sprečili električna ometanja od takvih uređaja.

BLUETOOTH POVEZIVANJE

Uključite radio i prebacite taster za izbor opsega na "MUSIC", biće emitovan zvuk "waiting for pairing", zatim pomoću vašeg telefona pronađite Bluetooth ime uređaja (RETRO TUNE) i povežite se.

FUNKCIJE

1. DC Priključak
2. USB Slot
3. TF Slot
4. Dugme za izbor opsega
5. Antena
6. Drška
7. Dugme za okretanje
8. Dugme za glasnoću
9. Prethodna
10. Play/Pause
11. Sledeća
12. Mode



SPECIFIKACIJE

Opšte specifikacije

Napon: DC: 5V1A
Izlazna snaga: 3.8W
Zvučnik: 5W 4Ω 57mm
Frekvencija prijema:
FM: 87,5-108MHZ
AM: 522-1620KHZ
SW: 5.6-22 MHZ
Punjava baterija: 3.7V 1200mAh 4.44Wh Li-ion baterija

Kako koristiti punjivu bateriju?

1. Uređaj koristi uklonjivu Li-ion punjivu bateriju, imajte na umu da je prvi put potrebno puniti 3-4 sata.
2. Obično, ako koristite punjivu bateriju, uređaj može da radi u sledećem vremenskom periodu:
Ako se koristi za USB/TF/BT --- oko 4 sata
Ako se koristi za radio --- oko 5.5 sati



UPOZORENJE:

Držite dalje od toplote i vatre. Ne stavljajte na jako sunce. Molimo vas da koristite punjenje baterije u skladu sa sigurnosnim uputstvima, nemojte puniti dok koristite uređaj. Nemojte uklanjati poklopac (ili zadnji deo), nema delova za servisiranje od strane korisnika. Servisiranje poverite kvalifikovanim servisnim radnicima.