



USER MANUAL BARACUDA 2 10PD 38.215.10



It is recommended to read this user manual carefully and keep it for future reference.

PRODUCT OVERVIEW



PRODUCT PARAMETERS

Capacity: 10,000mAh @ 3.85V (38.5Wh)	AC Input: 100-240V AC, 50/60Hz, 0.3A (Max)
Type-C Input: DC 5V-12V, PD 18W (Max)	Type-C Output: DC 5V-12V, PD 20W (Max)
USB A Output: DC 5V-3A, 9V-2A, 10V-2.25A, 12V-1.5A, 22.5W (Max)	
Type-C Cable Output: DC 5V-12V, PD 20W (Max)	Lightning Cable Output: DC 5V-2.4A (Max)
Wireless Output: 15W (Max), (2.5W Max for iWatch)	Size: 8.3 X 8.35 X 3.16 cm

PRODUCT INCLUDES

Power Bank Travel Charger x 1
 OPTIONAL ACESORIES
 AU Adapter Plug x 1
 EU Adapter Plug x 1
 UK Adapter Plug x 1



CHARGING & RECHARGING:

Before first use, please fully charge the power bank. Then, select one of the following charging methods and connect your device:

1. Built-in Type-C Cable
2. Built-in Lightning Cable
3. USB-A Port
4. Type-C Port
5. Wireless Charger (Supports iWatch charging)

Special Note:

Depress power button for 3-5s to enter low-current mode for charging low-power devices (e.g., iWatch, earphones).

Note:

If no device is detected after activation, the mode will auto-turn off after 2 hours. Re-enter by long-pressing the button for low-power charging.

CHARGING THE POWER BANK:

You can charge the power bank using the built-in AC plug or an external power adapter. Follow the steps below:

1. Using the Built-in Plug

Pull out the built-in AC plug from the power bank. If needed, attach one of the included regional adapter plugs (UK, EU, AU). Ensure you hear a "click" to confirm the adapter is securely attached. Then, plug it into a wall socket.

2. Using a Charging Cable

Connect one end of a charging cable to the USB-A or Type-C port of a power adapter. Plug the other end into the Type-C input port of the power bank.

CHECKING THE BATTERY LEVEL:

1. Check Battery Status

Quickly press the power button. The current battery percentage will appear on the digital display.


2. Turning Off the Display

Double-click the power button, or wait for about 30 seconds of inactivity. The display and power will automatically turn off.

WARNING


- This power bank is not a toy. Keep it out of reach of children.
- Do not expose the power bank to direct sunlight or extreme heat for extended periods.
- Do not submerge the power bank in water or allow it to get wet.
- Keep away from fire and other high-temperature sources.
- Avoid contact with harsh chemicals or corrosive substances.
- Do not use the power bank if it is damaged or has been modified.
- Do not insert foreign objects into any openings or ports.
- Do not disassemble, repair, or open the power bank under any circumstances.

UPUTSTVO BARACUDA 2 10PD 38.215.10



Preporučuje se da pažljivo pročitate ovaj korisnički priručnik i sačuvate ga za buduću upotrebu.

DIJAGRAM PROIZVODA



PARAMETRI PROIZVODA

Kapacitet: 10,000mAh @ 3.85V (38.5Wh)	AC ulaz: 100-240V AC, 50/60Hz, 0.3A (Max)
Type-C ulaz: DC 5V-12V, PD 18W (Max)	Type-C izlaz: DC 5V-12V, PD 20W (Max)
USB A izlaz: DC 5V-3A, 9V-2A, 10V-2.25A, 12V-1.5A, 22.5W (Max)	
Type-C Cable izlaz: DC 5V-12V, PD 20W (Max)	Lightning kabl izlaz: DC 5V-2.4A (Max)
Bežični izlaz: 15W (Max), (2.5W Max za iWatch)	Dimenzije: 8.3 X 8.35 X 3.16 cm

SADRŽAJ KUTIJE

Power Bank Travel Charger x 1
 OPCIONALNI PRIBOR
 AU adapter utikač x 1
 EU adapter utikač x 1
 UK adapter utikač x 1



PUNJENJE I PONOVRNO PUNJENJE

Pre prvog korišćenja, u potpunosti napunite power bank. Zatim izaberite jedan od sledećih načina punjenja i povežite svoj uređaj:

1. Ugrađeni Type-C kab
2. Ugrađeni Lightning kabl
3. USB-A Port
4. Type-C Port
5. Bežični punjač (podržava punjenje iWatch-a)

Posebna napomena:

Pritisnite dugme za napajanje 3-5 sekundi da biste ušli u režim niske struje za punjenje uređaja male potrošnje (npr. iWatch, slušalice).

Napomena:

Ako se nakon aktivacije ne detektuje nijedan uređaj, ovaj režim će se automatski isključiti nakon 2 sata. Ponovo se aktivira dugim pritiskanjem dugmeta za punjenje uređaja male potrošnje.

PONOVRNO PUNJENJE POWER BANKA

Možete puniti power bank pomoću ugrađenog AC utikača ili spoljnog punjača. Pratite korake u nastavku:

1. Korišćenje ugrađenog utikača

Izvučite ugrađeni AC utikač iz power banka. Ako je potrebno, pričvrstite jedan od priloženih adaptera za utičnice (UK, EU, AU). Uverite se da ste čuli „klik“ kako biste potvrdili da je adapter čvrsto pričvršćen. Zatim ga uključite u zidnu utičnicu.

2. Korišćenje kabla za punjenje

Povežite jedan kraj kabla za punjenje sa USB-A ili Type-C portom na punjaču. Drugi kraj povežite sa Type-C ulaznim portom na power banku.

PROVERA NIVOA BATERIJE

1. Provera statusa baterije

Brzo pritisnite dugme za napajanje. Trenutni procenat baterije će se prikazati na digitalnom ekranu.

2. Isključivanje ekrana

Duplo pritisnite dugme za napajanje ili sačekajte oko 30 sekundi neaktivnosti. Ekran i napajanje će se automatski isključiti.

UPOZORENJE

- Ovaj power bank nije igračka. Držite ga van domašaja dece.
- Ne izlažite power bank direktnoj sunčevoj svetlosti ili ekstremno toploti duži vremenski period.
- Ne potapajte power bank u vodu niti dozvolite da se pokvasi.
- Držite ga dalje od vatre i drugih izvora visoke temperature.
- Izbegavajte kontakt sa jakim hemikalijama ili korozivnim supstancama.
- Ne koristite power bank ako je oštećen ili modifikovan.
- Ne ubacujte strane predmete u bilo koji otvor ili port.
- Ni pod kojim okolnostima ne rastavljajte, ne popravljajte i ne otvarajte power bank.