


ENG



## USER MANUAL

**BLUES 38.187**

### Product parameter

Model: BLUES  
Material: ABS  
Wireless version: V5.3  
Music time: About 4-5 hours  
Talking time: About 4-5 hours  
Battery capacity:  
3.7 V, 30 mAh (earphones)  
3.7 V, 200 mAh (charging case)

Wireless pair name: BLUES  
Working distance:  $\geq 10$  m  
Frequency response: 20 Hz-20 KHz  
Charge interface: Type-c  
Compatibility: compatible with all wireless devices  
Charging time:  
1 hour (earphones)  
2 hours (charging case)

### Software default operation

#### BUTTONS

##### Play music

Touch the functionality button on one earbud. Touch it once to start/pause the music. Touch the button twice on the left earbud: select the previous track. Touch the button twice on the right earbud: select next track. Touch the button 3 times on the right earbud: volume is increased. Touch the button 3 times on the left earbud: the volume is decreased. Touch the button and hold for 2 seconds on any earbud: the voice assistant is activated.

##### Calls

Simply touch the functionality button on one earbud to take an incoming call and to hang-up. Long press the functionality button for 2 seconds to reject calls. Simply touch the functionality button again to hang-up during the phone call.


##### Charging

The voice prompt indicates that the battery of the charging box is low and needs to be charged. Only charge this product with the supplied USB-C Cable. Connect the USB Type-C cable to the charging port of the case. Plug the other end into a USB wall charger or computer that is powered on.

When charging the case, the LED light blinks.

Put the earbuds in the case and they will be automatically charged.

SRB



## KORISNIČKO UPUTSTVO

**BLUES 38.187**

### Parametri proizvoda

Model: BLUES  
Materijal: ABS  
Bežična verzija: V5.3  
Vreme za slušanje muzike: Oko 4-5 sati  
Vreme razgovora: Oko 4-5 sati  
Kapacitet baterije:  
3.7 V, 30 mAh (slušalice)  
3.7 V, 200 mAh (kutija za punjenje)

Naziv uređaja za povezivanje: BLUES  
Radna udaljenost:  $\geq 10$  m  
Frekventni opseg: 20 Hz ~ 20 KHz  
Interfejs za punjenje: Type-C  
Kompatibilnost: kompatibilne sa svim bežičnim uređajima  
Vreme punjenja:  
1 sat (slušalice)  
2 sata (kutija za punjenje)

### Podrazumevana softverska funkcionalnost

#### DUGMAD

##### Reprodukcija muzike

Dodirnite funkcijsko dugme na jednoj slušalici. Jednim dodirnom pokrećete/pauzirate muziku. Dvaput dodirnite dugme na levoj slušalici: prethodna pesma. Dvaput dodirnite dugme na desnoj slušalici: sledeća pesma. Tri puta dodirnite dugme na desnoj slušalici: pojačavanje zvuka. Tri puta dodirnite dugme na levoj slušalici: smanjivanje zvuka. Dodirnite i zadržite dugme na bilo kojoj slušalici 2 sekunde: aktivira se glasovni asistent.

##### Pozivi

Jednostavno dodirnite funkcijsko dugme na jednoj slušalici da prihvatite dolazni poziv i da završite razgovor. Dugim pritiskom dugmeta (2 sekunde) odbijate poziv. Ponovnim jednostavnim dodirnom dugmeta prekidate vezu tokom razgovora.

##### Punjenje

Glasovna poruka će vas obavestiti kada je baterija kutije za punjenje pri kraju i kada je potrebno punjenje. Ovaj proizvod punite isključivo priloženim USB-C kablom. Povežite USB Type-C kabl sa priključkom za punjenje na kutiji. Drugi kraj povežite sa USB punjačem ili uključenim računarom. Tokom punjenja kutije, LED lampica treperi. Stavite slušalice u kutiju – one će se automatski puniti.