



ENG

USER MANUAL



**BREEZE
38.140**

Product introduction




Specifications

Product name: Mini handheld fan
Model: BREEZE 38.140
Main material: ABS
Enter: 5V= 1A
Rated power: 3W
Input interface: Type-C
Battery capacity: 1200 mAh
Gear: third gear
Executive standard: GB4706.1-2005 GB4706.27-2008

Operation instruction

Indicator light	Low battery condition	White lights flash fast
	Charging state	White light Slow flicker
	Fully charged condition	white light on
Power Switch	Running state	white light on
	Press the 1 power button	Start 1st gear
	Press the 2 power button	Start 2st gear
	Press the 3 power button	Start 3st gear
	Press the 4 power button	Power off

Product parameter



Fan x 1 USB Charging cable x 1 Sling x 1 Specification x 1


Matters needing attention

- Do not put the product into the fire to avoid the risk of explosion.
- Do not use this product in a humid environment such as the bathroom, contact with water may cause product failure or damage.
- If the product accidentally enters water or other liquid, turn off the fan power switch immediately and let it dry completely before use.
- If the product does not charge, please replace the charging head or charging cable and try again.
- If the product is abnormally high temperature or deformed during the charging process, please stop charging immediately and contact customer service.

- When the product is charged, the charging cable should be pulled out in time, because overcharging will affect the service life of the product.
- Do not charge this product over the specified voltage.
- Do not disassemble or repair this product yourself.
- Do not knock or throw this product from a high altitude, repeated knocks may cause internal damage.
- Keep products out of reach of infants and young children.
- Do not use any form of fast charging head, so as not to cause product failure or damage.
- The product is not recommended for use in places where the temperature is higher than 60°C, continuous high temperature will affect the function of the product.
- When using the neck, please pay attention to prevent hair or foreign matter from entering the fan and causing product damage.
- Children need to be supervised by an adult.
- Do not block the air inlet and air outlet. Otherwise, the product may be damaged.


SRB

UPUTSTVO ZA UPOTREBU



**BREEZE
38.140**

Elementi proizvoda



Specifikacije

Naziv proizvoda: Ručni ventilator
Model i šifra: BREEZE 38.140
Materijal: ABS plastika
Ulazna snaga: 5V= 1A
Izlazna snaga: 3W
Ulaz: Type-C
Kapacitet baterije: 1200 mAh
Brzine: Tri brzine
Standard: GB4706.1-2005 GB4706.27-2008

Operacije

Svetlosni indikator	Nizak nivo baterije	Belo svetlo blinka ubrzano
	Stanje punjenja	Belo svetlo blinka usporeno
	Baterija napunjena u potpunosti	Belo svetlo
Dugme za paljenje i gašenje	Stanje rada	Belo svetlo
	Pritisnite dugme jednom	Pokreće se prva brzina
	Pritisnite dugme dva puta	Pokreće se druga brzina
	Pritisnite dugme tri puta	Pokreće se treća brzina
	Pritisnite dugme četiri puta	Gašenje

Sadržaj pakovanja



Ručni ventilator x 1 USB kabl za punjenje x 1 Traka za nošenje x 1 Uputstvo za upotrebu x 1

Upozorenja

- Ne stavljajte proizvod u vatru kako biste izbegli rizik od eksplozije.
- Nemojte koristiti ovaj proizvod u vlažnom okruženju kao što je kupatilo, kontakt sa vodom može dovesti do kvara ili oštećenja proizvoda.
- Ako proizvod slučajno uđe u vodu ili drugu tečnost, odmah isključite prekidač za napajanje ventilatora i ostavite da se potpuno osuši pre dalje upotrebe.
- Ako se proizvod ne puni, zamenite glavu za punjenje ili kabl za punjenje i pokušajte ponovo.
- Ako je proizvod neobičajeno visoke temperature ili je deformisan tokom procesa punjenja, odmah prekinite punjenje i kontaktirajte korisničku podršku.

- Kada se proizvod puni, kabl za punjenje trebalo bi na vreme izvući, jer će prekomerno punjenje uticati na vek trajanja proizvoda.
- Ne punite ovaj proizvod preko navedenog napona.
- Nemojte sami rastavljati ili popravljati ovaj proizvod.
- Ne udarajte i ne bacajte ovaj proizvod sa velike visine, ponovljeni udari mogu izazvati unutrašnja oštećenja.
- Držite proizvode van domašaja odojčadi i male dece.
- Ne koristite bilo koji oblik glave za brzo punjenje kako ne biste izazvali kvar ili oštećenje proizvoda.
- Proizvod se ne preporučuje za upotrebu na mestima gde je temperatura viša od 60°C, stalno visoka temperatura će uticati na funkciju proizvoda.
- Kada koristite ručku, obratite pažnju da sprečite dlake ili strane materije da uđu u ventilator i izazovu oštećenje proizvoda.
- Deca bi trebalo da budu pod nadzorom odrasle osobe dok koriste proizvod.
- Ne blokirajte ulaz i izlaz vazduha. U suprotnom, proizvod se može oštetiti.