


ENG

USER MANUAL FLOYD | 38.179



PRODUCT FEATURES:

- Bluetooth version: 5.4
- Voice assistant compatible: Siri
- Touch control: play/pause music, next/previous track, volume +/-, answer/reject calls, activate voice assistant
- Charging interface: Type-C
- Pocket-friendly, lightweight charging case

TECHNICAL SPECIFICATIONS

Bluetooth version	5.4
Supported profiles	A2DP, AVRCP, HSP, HFP
Bluetooth frequency	20 Hz - 20 KHz
Bluetooth range	10 m
Earbud battery	25 mAh
Charging case battery	230 mAh
Charging time	1.5 - 2h

-1-

PACKAGE CONTENTS:

If any of the following items are missing, please contact us immediately:

No.	Item	Quantity
1.	Wireless Earbuds FLOYD	1
2.	Type-C Charging Cable	1
3.	User Manual	1
4.	Silicone Earcaps - Size S	2
5.	Silicone Earcaps - Size L	2

BEFORE FIRST USE

To ensure the best user experience, fully charge both the earbuds and the charging case before first use.

-2-

CHARGING LED:

- When charging the case, the LED indicator will turn red.
- When fully charged, the red light will turn off.

Power ON:

1. Open the charging case and remove the earbuds.
2. Press and hold both earbuds for 2 seconds.

Power OFF:

1. Place both earbuds back into the charging case.
2. Press and hold either earbud for 6 seconds to power off.

CONNECTING EARBUDS TO YOUR PHONE

- Open the charging case and take out the earbuds.
- The earbuds will automatically turn on and pair with each other.
- On your phone, search for and select "FLOYD" to connect.

Note: If not connected within 3 minutes, the earbuds will power off automatically

-3-

TOUCH CONTROLS

Previous track:

Tap the left earbud 3 times.

Next track:

Tap the right earbud 3 times.

Play/Pause music:

Single tap on either earbud.

Answer/End call:

Single tap on either earbud.

Reject call:

Press and hold either earbud.

Volume up:

Double tap the right earbud.

Volume down:

Double tap the left earbud.

Voice assistant (Siri):

Press and hold either earbud for 2 seconds and the Voice Assistance/Siri will be activated.

Note: Touch control functions may vary slightly depending on your device.

-4-


SAFETY INSTRUCTIONS

- Earbuds should be stored in a dry and ventilated environment to avoid contact with oil, steam, moisture, dust, etc., to avoid affecting product performance.
- Avoid using irritating organic solvents or items containing these ingredients to clean earbuds.
- Earbuds should be used correctly and in a standardized manner as required, and attention to the impact of the use environment as well.
- To ensure smooth connection, the distance between the phone and earbuds should be within 10 meters.
- If earbuds has other problems such as poor connection or communication, please do not disassemble the earbuds body and accessories without permission, otherwise the warranty will not be granted.
- Please choose a standard car charger or a qualified charger designated by our company to charge the earbuds.
- To ensure your normal use of earbuds, please ensure that the earbuds has sufficient power.

-5-

SRB

UPUTSTVO FLOYD | 38.179



KARAKTERISTIKE PROIZVODA:

- Verzija Bluetooth-a: 5.4
- Kompatibilno sa glasovnim asistentom: Siri
- Kontrola dodirom: puštanje/pauziranje muzike, sledeća/prethodna pesma, jačina zvuka +/-; prihvatanje/odbijanje poziva, aktivacija glasovnog asistenta
- Punjenje: Type-C
- Prikladno za džep / lagana futrola

TEHNIČKE SPECIFIKACIJE

Verzija Bluetooth-a	5.4
Podržani profili	A2DP, AVRCP, HSP, HFP
Frekvencija Bluetooth-a	20 Hz - 20 KHz
Domet Bluetooth-a	10 m
Baterija slušalice	25 mAh
Baterija kućišta	230 mAh
Vreme punjenja	1.5 - 2h

-1-

SADRŽAJ PAKOVANJA:

Ako nedostaje bilo koji od dole navedenih delova, kontaktirajte nas odmah:

R.broj	Stavka	Količina
1.	Bežične slušalice FLOYD	1
2.	Type-C kabl za punjenje	1
3.	Uputstvo za upotrebu	1
4.	Silikonski nastavci - veličina S	2
5.	Silikonski nastavci - veličina L	2

PRE PRVE UPOTREBE:

Za najbolje korisničko iskustvo, preporučuje se da napunite i kutiju i slušalice pre prve upotrebe.

-2-

LED INDIKATOR PUNJENJA:

- Kada punite kutiju, LED lampica svetli crveno.
- Kada je potpuno napunjena, crveno svetlo se gasi.

Uključivanje (ON):

1. Otvorite kutiju za punjenje i izvadite slušalice.
2. Dugim pritiskom (2 sekunde) na obe slušalice ih uključite.

Isključivanje (OFF):

1. Vratite obe slušalice u kutiju za punjenje.
2. Dugim pritiskom (6 sekundi) na bilo koju slušalicu ih isključite.

POVEZIVANJE SLUŠALICA SA TELEFONOM

- Otvorite kutiju i izvadite slušalice.
- Slušalice će se automatski uključiti i međusobno povezati.
- Na telefonu pronađite uređaj „FLOYD“ i povežite se.

Napomena: Ako se ne povežu u roku od 3 minuta, slušalice se automatski isključuju.

-3-

KONTROLE DODIROM

Prethodna pesma:

3 puta dodirnite levu slušalicu.

Sledeća pesma:

3 puta dodirnite desnu slušalicu.

Pauza / puštanje muzike:

1 dodir na bilo koju slušalicu.

Primanje / prekidanje poziva:

1 dodir na bilo koju slušalicu.

Odbijanje poziva:

Dugim pritiskom na bilo koju slušalicu odbijate poziv.

Povećavanje jačine zvuka:

2 puta dodirnite desnu slušalicu.

Smanjivanje jačine zvuka:

2 puta dodirnite levu slušalicu.

Glasovni asistent (Siri):

Dug pritisak na bilo koju slušalicu 2 sekunde i glasovni asistent će biti aktiviran.

Napomena: funkcije dodirom mogu se razlikovati u zavisnosti od uređaja.

-4-

BEZBEDNOSNA UPUTSTVA

- Slušalice treba čuvati na suvom i provetrenom mestu kako bi se izbegao kontakt sa uljem, parom, vlagom, prašinom itd., kako ne bi došlo do smanjenja performansi proizvoda.
- Izbegavajte korišćenje iritantnih organskih rastvarača ili predmeta koji sadrže te sastojke za čišćenje slušalice.
- Slušalice treba koristiti pravilno i na standardizovan način, uz obraćanje pažnje na uslove okruženja. Da bi veza bila stabilna, rastojanje između telefona i slušalice ne bi trebalo da prelazi 10 metara.
- Ako slušalice imaju druge probleme kao što su loša veza ili komunikacija, nemojte ih rastavljati bez dozvole, jer u suprotnom garancija neće biti priznata.
- Molimo koristite standardni punjač za automobil ili kvalifikovani punjač koji preporučuje naša kompanija za punjenje slušalice.
- Da biste slušalice koristili normalno, uverite se da imaju dovoljno napunjenu bateriju.

-5-