

## UPUTSTVO ZA UPOTREBU


### NEUTRINO 38.040 | POMOĆNA BATERIJA

Ovo je koristan punjač telefona za hitne slučajeve. Možete ga koristiti za punjenje digitalnih uređaja bilo kada i bilo gde.

### LED indikator

- Dugme: Pritisnite dugme jednom da ga uključite; Dvaput kliknite na dugme da biste isključili napajanje.
- Pomoćna baterija stanje punjenja: 25% 50% 75% 100% (5 25%) naizmenično treperi, belo svetlo treperi, puno svakog svetla, belo svetlo je uključeno, 100% puno 6, četiri svetla su uključena;
- Stanje pražnjenja pomoćne baterije: Trenutna lampica napajanja je bela i stalno svetli. Nakon što se svaki indikator potroši, lampica će se ugasi dok se ne potroši napajanje.

- ① USB-1 izlaz
- ② Type-C ulaz i izlaz
- ③ USB-2 izlaz
- ④ Dugme za paljenje/gašenje uređaja
- ⑤ 25% indikator
- ⑥ 100% indikator



### Specifikacije proizvoda:

Kapacitet: 5000mAh 3.7V 18.5Wh  
Type C ulaz: DC5V/2.1A  
Type C izlaz: DC5V/2.1A  
USB-1/2 Izlaz: DC5V/2.1A  
Dimenzije: 99 \* 62 \* 15 mm  
Baterija: Li-polimer baterija  
Materijal: ABS

### Napunite pomoćnu bateriju

- Uz uređaj dobijate Type-C kabl. Odaberite odgovarajući punjač za punjenje uređaja.

### Pažnja

- Ovaj proizvod nije voodootporan. Nemojte ga kvasiti ili koristiti tokom jake kiše.
- Ako proizvod slučajno padne u vodu, koristite čistu krpu da upije vodu na površini proizvoda i nemojte odmah uključivati uređaj.
- Nemojte bacati pomoćnu bateriju u vatru da biste izbegli eksploziju.
- Nemojte koristiti niti čuvati pomoćnu bateriju u vrućem (preko 50 stepeni Celzijusa), vlažnom ili korozivnom okruženju.

- Čuvajte van domašaja dece. Ne ostavljajte proizvod bez nadzora dok je u upotrebi.
- Ne otvarajte uređaj – opasnost od strujnog udara.
- Proverite da li je pomoćna baterija prikladna za vaš mobilni telefon ili elektronsku opremu pre upotrebe.
- Ako pomoćna baterija nije korišćena duže vreme, napajanje ugrađene baterije može da se isprazni. Da biste rešili ovaj problem, puniti punjač 2-3 sata. Kada ima malo snage, punjač će ponovo funkcionisati.
- Da biste izbegli oštećenje baterije, koristite je najmanje jednom u svakih 6 meseci.
- Nemojte koristiti mobilni telefon dok se baterija puni pomoću pomoćne baterije i nemojte ga puniti preko noći.
- Kada povezujete pomoćnu bateriju sa uređajem, koristite kablove za punjenje i konektore koje ste dobili od ovlašćenog proizvođača. Korišćenje kablova za punjenje ili konektora od neovlašćenog proizvođača može izazvati teške ili smrtonosne povrede i gubitak imovine i oštećenje proizvoda i uređaja.
- Pomoćna baterija je kompatibilna sa USB kablom/adaptrom Apple® proizvoda (nije uključen).
- Ne ostavljajte pomoćnu bateriju da radi u hermetički zatvorenom prostoru pod sunčevim zracima, to može dovesti do prekoračenja maksimalne radne temperature.
- Ostavite pomoćnu bateriju neaktivnom tokom punjenja, nemojte nastaviti da puniti drugi uređaj i istovremeno puniti pomoćnu bateriju.

## USER MANUAL


### NEUTRINO 38.040 | POWER BANK

This is a useful emergency phone charger. You can use it to charge your digital devices anytime and anywhere.

### LED indicator

- Switch part: Press button 1 time to turn on the light; Press button 3-5 seconds to turn off the light.
- Power bank Charging state: 25% 50% 75% 100% (5 25%) in turn flashing, the white light flashes, full of each light, the white light is on, 100% full of 6, four lights are on;
- Power bank discharging state: The current power lamp is white and steady on. After every indicator is used up, the lamp will turn off until the power is exhausted.

- ① USB-1 Output
- ② Type-C Input & Output
- ③ USB-2 Output
- ④ Switch
- ⑤ 25% indicator
- ⑥ 100% indicator



### Product Specifications:

Capacity: 5000mAh 3.7V 18.5Wh  
Type-C Input: DC5V/2.1A  
Type-C Output: DC5V/2.1A  
USB-1/2 Output: DC5V/2.1A  
Size: 99\*62\*15mm  
Battery: Li-Polymer battery  
Material: ABS

### Charge the power bank

- With this product we provide Type-C cable. You can choose the appropriate adapter to connect the power bank and the power supply.

### Attention

- This product is not waterproof. Please do not wet it or use it during heavy rain.
- If the product accidentally falls into the water, please use a clean cloth to absorb the water on the product's surface, and do not switch on the device immediately.
- Please do not throw the power bank into fire to avoid explosion.
- Do not use or store the power bank in a hot (over 50 degree Celsius), wet or corrosive environment.
- Please keep out of reach of children. Do not leave product unattended whilst in use.

- Do not open the device – shock hazard.
- Check whether the power bank is suitable for your mobile phone or electronic equipment prior to use.
- If the power bank has not been used for a long time, the power of the built-in battery can be depleted. To solve this problem, charge the charger for 2-3 hours. When it has some power, the charger will function again.
- In order to avoid damaging the battery, please use it at least once in every 6 months.
- Do not use the mobile phone whilst the battery is being charged with the power bank and do not charge the power bank overnight.
- When connecting the power bank to the device, please use the charging cables and connectors provided from the authorized maker. The use of charging cables or connectors from unauthorized maker may cause severe or fatal injuries and property loss and damage to the product and the device.
- Power Bank is compatible with Apple® Product USB cable/adaptor (Not Included).
- Do not leave the power bank operating in airtight space under sunshine, may cause the maximum operating temperature to be exceeded.
- Keep the power bank idle when recharging, do not keep charging other device and recharging power bank at the same time.