

ENG

USER MANUAL OPERA 38.097



It is recommended to read this user manual carefully and keep it for future reference

OPERATING INSTRUCTIONS:

1. POWER BUTTON

Power ON/OFF - Press for 1.5 seconds to turn it ON or OFF.
Mode Switch - Short press BT-TF.
Light Switch - Double Press.

2. MUSIC & VOLUME

Next song - Long press 1.5 seconds to move to the next song.
Volume Up - Short press to increase the volume.

3. MUSIC & VOLUME

Previous song - Long press 1.5 seconds to move to the previous song.
Volume Down - Short press to decrease the volume.

4. PAUSE & PHONE CALL

Play/Pause - Short press to pause or play a song.
Answer/End Phone Call - Short press to answer. During call, short press to end the call.
Reject a call - Incoming call, long press 1.5 second to reject.
Enter/Exit TWS mode - Ensure the two speakers is not connected, long press one or two speaker to enter the TWS mode, double press again to exit the TWS mode.
Redial last number - Under BT mode, press 2 times.



5. TF Card

6. TYPE - C PORT



HOW TO CHARGE

1. Locate the Type-C charging cable:

Find the Type-C charging cable that came with your speaker.

2. Connect Type-C cable to the speaker:

Insert the small end of the Type-C charging cable into the charging port located on the side of the speaker.

3. Connect the cable to a power source:

If using a computer, insert the larger end of the charging cable into a USB port on your computer.

4. Verify the connection:

Ensure that the connections are secure and the charging indicator on the speaker is illuminated, indicating that it is charging.

PRODUCT SPECIFICATIONS

Input: DC 5V 1A
Output Power: 1*5W
Battery Capacity: 1200 mAh
Bluetooth Version: 5.4
Transmission Distance: 10 meters
70% Volume Play Time: Up to 5 hours
Waterproof: IPX7
Charging Interface: Type-C

CONTENTS:

1 x Waterproof Wireless Speaker
1 x USB A-C Charging Cable
1 x User manual

SRB

UPUTSTVO ZA UPOTREBU OPERA 38.097



Preporučuje se da pažljivo pročitate ovaj korisnički priručnik i sačuvate ga za buduću upotrebu.

UPUTSTVO ZA UPOTREBU

1. DUGME ZA NAPAJANJE

Uključivanje/isključivanje - Pritisnite i držite 1.5 sekundi da biste uključili ili isključili uređaj.
Prebacivanje moda - Kratko pritisnite BT-TF.
Prekidač svetla - Dvput pritisnite.

2. MUZIKA I JAČINA ZVUKA

Sledeća pesma - Pritisnite i držite 1.5 sekundi da biste prešli na sledeću pesmu.
Povećanje jačine zvuka - Kratko pritisnite da biste povećali jačinu zvuka.

3. MUZIKA I JAČINA ZVUKA

Prethodna pesma - Pritisnite i držite 1.5 sekundi da biste prešli na prethodnu pesmu.
Smanjenje jačine zvuka - Kratko pritisnite da biste smanjili jačinu zvuka.

4. PAUZA I TELEFONSKI POZIV

Reprodukcija/Pauza - Kratko pritisnite da biste pauzirali ili nastavili pesmu.
Prihvatanje/završavanje poziva - Kratko pritisnite da biste prihvatili poziv. Tokom poziva, kratko pritisnite da biste završili poziv.
Odbijanje poziva - Kada je poziv dolazni, pritisnite i držite 1.5 sekundi da biste odbili poziv.
Uključivanje/isključivanje TWS moda - Pobrinite se da dva



zvučnika nisu povezana, pritisnite i držite jedan ili oba zvučnika da biste ušli u TWS mod, a dvaput pritisnite ponovo da biste izašli iz TWS moda. Ponovno biranje poslednjeg broja - U BT modu, pritisnite dva puta.

5. TF Kartica

6. TYPE - C PORT



KAKO PUNITI

1. Pronađite Type-C kabl za punjenje:

Pronađite Type-C kabl za punjenje koji je došao uz vaš zvučnik.

2. Povežite Type-C kabl sa zvučnikom:

Umetnite manji kraj Type-C kabla za punjenje u priključak za punjenje koji se nalazi sa strane zvučnika.

3. Povežite kabl sa izvorom napajanja:

Ako koristite računar, umetnite veći kraj kabla u USB port na vašem računaru.

4. Proverite vezu:

Proverite da li su konekcije sigurno povezane i da li je indikator punjenja na zvučniku upaljen, što označava da se zvučnik puni.

SPECIFIKACIJE PROIZVODA

Ulaz: DC 5V 1A
Izlazna snaga: 1*5W
Kapacitet baterije: 1200 mAh
Bluetooth verzija: 5.4
Udaljenost prenosa: 10 metara
Vreme reprodukcije pri 70% jačine zvuka: Do 5 sati
Otpornost na vodu: IPX7
Interface za punjenje: Type-C

SADRŽAJ:

1 x Vodootporni bežični zvučnik
1 x USB A-C kabl za punjenje
1 x Uputstvo za upotrebu