


EN



USER MANUAL

POINT PAD 3 IN 138.121.10


Please read this manual before using the device to ensure safe and proper use.

Note: Wireless charging option is only possible if the Type-C cable is connected.

Important: only use included accessories or certified and tested accessories to charge this device. Using third party accessories can influence the item safety. This item can only be used with items that are compatible with wireless charging.

DEVICE LAY-OUT

1. Type-C in
2. Wireless charging surface for iWatch.
- (Charging pad optimized for Apple iWatch only.)
3. Wireless charging surface for earbuds.
4. Wireless charging surface for phone.



SPECIFICATIONS :

Type-C input: 5V/3A, 9V/3A (Max.)
Wireless output: Phone 5W/7.5W/10W/15W (Max.)
Watch 2.5W (Max.). Charging pad optimized for Apple iWatch only. TWS earbuds 5W (Max.)

USING THE WIRELESS CHARGER


- First plug in the wireless charger using the included Type-C cable into the USB port of your power adapter.
- Make sure your all devices are compatible with wireless charging.
- Put your wireless charging enabled device on the wireless charging surfaces(2,3,4.).

WARNING!

- Before charging, ensure that your devices support wireless charging. Using incompatible devices may result in ineffective charging or damage to your devices.
- Remove any metal accessories, such as cases or straps, from your devices before placing them on the charger. Metal can interfere with wireless charging and may cause overheating or damage to the charger.
- Place the wireless charger on a flat, stable surface with adequate ventilation. Avoid covering the charger during use, as this can lead to overheating and potential safety hazards.
- Keep an eye on your devices while they are charging. If you notice any unusual behavior, such as excessive heat or slow charging, stop using the charger immediately.
- Avoid exposing the charger to water or other liquids. Water damage can cause electrical hazards and may void the warranty.

- Disconnect the charger from the power source when not in use to prevent energy wastage and reduce the risk of electrical hazards.
- Use only provided charging cables provided by the manufacturer. Using third-party accessories may damage your devices or cause them to malfunction.
- Keep the charger and any associated cables out of reach of children and pets to prevent accidents or damage to the devices.
- Some phone cases may block the wireless charging.
- When the mobile device is not placed on the charging surface accurately, your mobile device may not charge properly.
- Please do not expose this device to moisture or heath sources.

SRB



UPUTSTVO

POINT PAD 3 IN 138.121.10


Molimo vas da pročitate ovaj priručnik pre upotrebe uređaja kako biste obezbedili bezbednu i pravilnu upotrebu.

Napomena: Bežično punjenje je moguće samo ako je Type-C kabl povezan.

Važno: Koristite samo priložene ili sertifikovane i testirane dodatke za punjenje ovog uređaja. Korišćenje dodatoka trećih strana može uticati na bezbednost uređaja. Ovaj uređaj može se koristiti samo sa uređajima koji su kompatibilni sa bežičnim punjenjem.

RASPORED UREDAJA

1. Type-C ulaz
2. Bežična površina za punjenje iWatch-a.
- (Ploča za punjenje optimizovana samo za Apple iWatch.)
3. Bežična površina za punjenje slušalice.
4. Bežična površina za punjenje telefona.



SPECIFIKACIJE :

Type-C ulaz: 5V/3A, 9V/3A (Max.)
Bežični izlaz: Telefon 5W/7.5W/10W/15W (Max.)
Slušalice 2.5W (Max.)
Ploča za punjenje optimizovana samo za Apple iWatch.
TWS slušalice 5W (Max.).

UPOTREBA BEŽIČNOG PUNJAČA

- Prvo priključite bežični punjač koristeći priloženi Type-C kabl u USB port vašeg adaptera za napajanje.
- Uverite se da su svi vaši uređaji kompatibilni sa bežičnim punjenjem.
- Postavite uređaj sa mogućnošću bežičnog punjenja na odgovarajuće površine za bežično punjenje (2, 3, 4).

UPOZORENJE!

- Pre punjenja, uverite se da vaši uređaji podržavaju bežično punjenje. Korišćenje nekompatibilnih uređaja može rezultirati neefikasnim punjenjem ili oštećenjem vaših uređaja.
- Uklonite bilo kakve metalne dodatke, kao što su futrole ili kaiševi, sa vaših uređaja pre nego što ih stavite na punjač. Metal može ometati bežično punjenje i izazvati pregrevanje ili oštećenje punjača.
- Postavite bežični punjač na ravnu, stabilnu površinu sa adekvatnom ventilacijom. Izbegavajte da pokrijete punjač tokom upotrebe, jer to može dovesti do pregrevanja i potencijalnih bezbednosnih opasnosti.
- Pratite svoje uređaje dok se pune. Ako primetite bilo kakvo neobično ponašanje, kao što je prekomerno zagrevanje ili sporo punjenje, odmah prestanite sa korišćenjem punjača.
- Izbegavajte izlaganje punjača vodi ili drugim tečnostima. Oštećenje vodom može izazvati električne opasnosti i može poništiti garanciju.

- Isključite punjač iz izvora napajanja kada se ne koristi kako biste sprečili gubitak energije i smanjili rizik od električnih opasnosti.
- Koristite samo priložene kablove za punjenje koje je obezbedio proizvođač. Korišćenje dodatoka trećih strana može oštetiti vaše uređaje ili izazvati njihov kvar.
- Držite punjač i sve povezane kablove van doseg dece i kućnih ljubimaca kako biste sprečili nesreće ili oštećenje uređaja.
- Neke futrole za telefon mogu blokirati bežično punjenje.
- Kada mobilni uređaj nije tačno postavljen na površinu za punjenje, vaš uređaj možda neće biti pravilno napunjen.
- Molimo vas da ne izlažete ovaj uređaj vlazi ili izvorima toplote.