

06 Resetting Tag 06.1 Remove The Tag From Find My App: Open Find My app and select the "Items" tab. Tap on your N Tag from the list. Please ensure "Lost Mode" is disabled. Scroll to the bottom of the screen and tap "Remove Item". A summary will open, tap "Remove" to confirm. 06.2 Factory Reset Your Tag: After successfully removing the Tag from Find My app, press the Tag's function button four times rapidly and then hold it a fifth time until you hear a ringing chime. The Tag is now reset and ready to be paired to a new Apple ID.	07 Extras 07.1 Unwanted tracking: If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways: 1. If you have an iPhone, iPad, Find My will send a notification to your Apple device.This feature is available on iOS or iPadOS 14.5 or later. 2. If you don't have an ios device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specifically to discourage people from trying to track you without your knowledge.	08 The fine print This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure conditions without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.	08 The fine print This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and,if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from thatto which the receiveris connected.	09 About Apple Find My The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, or Mac. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location. Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Watch, iPad, iPadOS, Mac, and macOS are the trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.	USER MANUAL TAG FINDER 38.139.10
--	---	---	---	---	---

06 Resetovanje taga 06.1 Uklonite Tag iz Find My aplikacije: Otvorite Find My aplikaciju i izaberite tab „Items“ . Tapnite na svoj Tag sa liste. Proverite da li je opcija „Lost Mode“ isključena. Pomaknite se na dno ekrana i tapnite na „Remove Item“. Pojaviće se sažetak, tapnite na „Remove“ da biste potvrdili. 06.2 Vraćanje na fabrička podešavanja (Factory Reset) vašeg Taga: Nakon što uspešno uklonite Tag iz Find My aplikacije, pritisnite funkcionišući taster na Tagu četiri puta brzo, a zatim ga držite peti put dok ne čujete zvonasti signal. Tag je sada resetovan i spreman da se poveže sa novim Apple ID-jem.	07 Dodatne funkcije 07.1 Neželjeno praćenje: Ako bilo koji Find My mrežni dodatak koji je odvojen od svog vlasnika bude primećen kako se kreće sa vama tokom vremena, bićete obavešteni na jedan od dva načina: 1. Ako imate iPhone ili iPad, Find My će poslati obaveštenje na vaš Apple uređaj. Ova funkcija je dostupna na iOS ili iPadOS 14.5 i novijim verzijama. 2. Ako nemate iOS uređaj ili pametan telefon, Find My mrežni dodatak koji nije sa svojim vlasnikom određeni period vremena, emitovaće zvuk kada se pomeri. Ove funkcije su kreirane kako bi se sprečilo neželjeno praćenje i zaštitili vaša privatnost i sigurnost.	08 Sitnim slovima Ovaj uređaj je u skladu sa delom 15 FCC pravila. Rad uređaja podložan je sledećim uslovima: (1) Ovaj uređaj ne sme izazvati štetne smetnje, i (2) Ovaj uređaj mora prihvatiti bilo kakve smetnje koje se prime, uključujući smetnje koje mogu izazvati neželjeni rad uređaja. Napomena: Proizvođač nije odgovoran za bilo kakve radio ili TV smetnje izazvane neovlašćenim modifikacijama ili promenama na ovoj opremi. Takve modifikacije ili promene koje nisu izričito odobrene od strane odgovorne strane za usklađenost mogu poništiti korisnikovu dozvolu za upotrebu ovog uređaja. Uređaj je ocenjen da ispunjava opšte zahteve za izlaganje RF (radio-frekventnoj) energiji. Uređaj se može koristiti u prenosivim uslovima izlaganja bez ograničenja.Federalna Komisija za Komunikacije (FCC) Izjava o Izlaganju Zračenju: Snaga je toliko niska da nije potrebno vršiti izračunavanje izlaganja RF energiji.	08 Sitnim slovima Ova oprema je testirana i ustanovljeno je da je u skladu sa ograničenjima za Class B digitalni uređaj, u skladu sa delom 15 FCC pravila. Ova ograničenja su dizajnirana da pruže razonodnu zaštitu od štetnih smetnji u stambenim instalacijama. Ova oprema generiše, koristi i može zračiti radio frekventnu energiju i, ako nije instalirana i korišćena u skladu sa uputstvima, može izazvati štetne smetnje u radio komunikaciji. Međutim, ne postoji garancija da smetnje neće nastati u određenoj instalaciji. Ako ova oprema izazove štetne smetnje u prijemu radija ili televizije, što se može utvrditi isključivanjem i uključivanjem opreme, korisniku se savetuje da pokuša da ispravi smetnje jednom ili više sledećih mera: promenite orijentaciju ili pomerite prijemnu antenu, povećajte razdaljinu između opreme i prijemnika. Povežite opremu na utičnicu na različitom strujnom krugu od onog na kojem je prijemnik povezan.	09 O Apple Find My Apple Find My mreža pruža jednostavan i siguran način za lociranje ličnih predmeta na mapi koristeći aplikaciju Find My na vašem iPhone-u, iPad-u ili Mac-u. Jednostavno uparite vaš proizvod sa Apple Find My aplikacijom i prikazite ga zajedno sa vašim Apple uređajima. Ako vaš predmet ikada nestane, možete ga staviti u "Lost Mode" kako biste prikazali poruku i kontakt informacije bilo kome ko ga pronađe. Find My mreža je enkriptovana i anonimna, što znači da nijedna druga osoba, pa ni Apple ili proizvođač vašeg predmeta, ne može videti njegovu lokaciju. Upotreba oznake „Works with Apple“ znači da je proizvod dizajniran da specifično funkcioniše sa tehnologijom koja je identifikovana na oznaci i da je sertifikovan od strane proizvođača proizvoda da ispunjava specifikacije i zahteve za Apple Find My mrežu. Apple nije odgovoran za rad ovog uređaja, upotrebu ovog proizvoda ili njegovu usklađenost sa sigurnosnim i regulatornim standardima. Apple, Apple Watch, iPad, iPadOS, Mac, i macOS su zaštitni znakovi kompanije Apple Inc., registrovani u SAD-u i drugim zemljama, IOS je zaštitni znak ili registrovani zaštitni znak kompanije Cisco u SAD-u i drugim zemljama i koristi se pod licencom.	KORISNIČKO UPUTSTVO TAG FINDER 38.139.10
--	---	---	---	---	---

Index 01 Getting Started 02 Add Your Tag 03 Locate Your Tag 04 Notifications 05 When Your Tag Is Lost 06 Resetting Tag 07 Extras 08 The Fine Print	01 Getting started 01.1 Power On / Off: Press the Tag Function Button once to turn it on. It should beep once to indicate that it is powered on. To power off, hold the same button for at least three seconds. You will hear two beeps to indicate that your Tag is powered off. 01.2 Check For Updates: To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.	02 Add Your Tag 02.1 Start The App Open Find My app on your supported iPhone. 02.2 Connect Your N Tag Press the function button once to power on your Tag. Tap+, then "Add Other Item" . Once your Tag is located, tap "connect" Enter a name and choose an emoji for your Tag and tap "Continue". Find My will ask for confirmation to add your Tag to your Apple ID Tag "Agree" Tap "Finish" and your Tag will be set up and ready to be used.	03 Locate Your Tag 03.1 Find Tag When It's Nearby: Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your N Tag from the list. Tap "Play Sound" to make your N Tag beep. Tap "Stop Sound" to stop the beeps once you find. 03.2 Find Tag's Location: Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your Tag from the list. Your Tag's location will appear on the Map with a time stamp of when the item was located. To navigate to the Tag's location, tap "Directions" to open Apple Maps.	04 Notifications 04.1 Enabling "Notify When Left Behind": Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your Tag from the list. Under "Notifications" enable the "Notify When Left Behind" toggle. You will receive a notification when you leave your Tag behind and it's no longer in range of your device. 04.2 Enabling "Notify When Found": Under "Notifications", enable the "Notify When Found" toggle. When your Tag is seen by another Find My network device, you will receive a notification of its location. Note: " Notify When Found" can only be activated when your Tag is out of range.	05 When Your Tag Is Lost 05.1 Enabling "Lost Mode": Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your Tag from the list. Under "Lost Mode" tap "Enable" A screen detailing Lost Mode will pop up, tap "Continue" Enter your phone number or email address and tap "Next". You may enter a message that will be shared with the person that finds your item. Tap "Activate" to enable "Lost Mode" Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled. Note: When " Lost Mode" is enabled, your N Tag is locked and cannot be paired to a new device.
---	--	---	--	---	---

Indeks 01 Početak 02 Dodajte svoj tag 03 Pronađite svoj tag 04 Obaveštenja 05 Kada je vaš tag izgubljen 06 Resetovanje taga 07 Dodatne funkcije 08 The Fine Print	01 Početak 01.1 Uključivanje / Isključivanje: Pritisnite funkcionišući taster na tagu jednom da biste ga uključili. Trebalo bi da čujete jedan zvučni signal koji označava da je tag uključen. Da biste ga isključili, držite isti taster najmanje tri sekunde. Čujete dva zvučna signala koji označavaju da je vaš tag isključen. 01.2 Provera ažuriranja: Da biste koristili Apple Find My aplikaciju za lociranje ovog predmeta, preporučuje se najnovija verzija iOS-a, iPadOS-a ili macOS-a. Find Items aplikacija na Apple Watch-u zahteva najnoviju verziju watchOS-a.	02 Dodajte svoj tag 02.1 Pokrenite aplikaciju Otvorite Find My aplikaciju na svom podržanom iPhone-u. 02.2 Povežite svoj Tag Pritisnite funkcionišući taster jednom da biste uključili svoj Tag. Tapnite na "+" zatim izaberite „Add Other Item“ (Dodaj drugi predmet). Kada vaš Tag bude lociran, tapnite na „Connect“ (Poveži). Unesite ime i izaberite emoji za svoj Tag, zatim tapnite na „Continue“ (Nastavi). Find My će tražiti potvrdu da dodate svoj Tag na svoj Apple ID, tapnite na „Agree“ (Slažem se). Tapnite na „Finish“ (Završi) i vaš Tag će biti postavljen i spreman za upotrebu.	03 Pronađite svoj tag 03.1 Pronađite Tag kada je u blizini: Otvorite Find My aplikaciju i izaberite tab „Items“ (Predmeti) ili otvorite Find Items aplikaciju na svom Apple Watch-u. Tapnite na svoj Tag sa liste. Tapnite na „Play Sound“ (Reprodukuj zvuk) da biste čuli zvučni signal sa svog Taga. Tapnite na „Stop Sound“ (Zaustavi zvuk) da prestanete sa zvučnim signalima kada pronađete svoj Tag. 03.2 Pronađite lokaciju Taga: Otvorite Find My aplikaciju i izaberite tab „Items“ (Predmeti) ili otvorite Find Items aplikaciju na svom Apple Watch-u. Tapnite na svoj Tag sa liste. Lokacija vašeg Taga će se prikazati na mapi, uz vremensku oznaku kada je predmet lociran. Da biste se uputili ka lokaciji Taga, tapnite na „Directions“ (Uputstvo) da biste otvorili Apple Maps.	04 Obaveštenja 04.1 Aktiviranje opcije „Notify When Left Behind“ (Obavesti kada ostavite iza sebe): Otvorite Find My aplikaciju i izaberite tab „Items“ ili otvorite Find Items aplikaciju na svom Apple Watch-u. Tapnite na svoj Tag sa liste. Pod „Notifications“ omogućite opciju „Notify When Left Behind“. Dobićete obaveštenje kada ostavite svoj Tag iza sebe i kada više nije u dometu vašeg uređaja. 04.2 Aktiviranje opcije „Notify When Found“ (Obavesti kada bude pronađen): Pod „Notifications“ omogućite opciju „Notify When Found“. Kada vaš Tag bude primećen od strane drugog uređaja u Find My mreži, dobićete obaveštenje o njegovoj lokaciji. Napomena: „Notify When Found“ može biti aktivirana samo kada je vaš Tag van dometa.	05 Kada je vaš tag izgubljen 05.1 Aktiviranje opcije „Lost Mode“ (Režim izgubljenog predmeta): Otvorite Find My aplikaciju i izaberite tab „Items“ ili otvorite Find Items aplikaciju na svom Apple Watch-u. Tapnite na svoj Tag sa liste. Pod „Lost Mode“ tapnite na „Enable“. Na ekranu će se pojaviti detalji o „Lost Mode“-u, tapnite na „Continue“. Unesite svoj broj telefona ili email adresu, a zatim tapnite na „Next“. Možete uneti poruku koja će biti podeljena sa osobom koja pronađe vaš predmet. Tapnite na „Activate“ da biste omogućili „Lost Mode“. Napomena: Kada je „Lost Mode“ aktiviran, opcija „Notify When Found“ automatski se aktivira. Napomena: Kada je „Lost Mode“ aktiviran, vaš Tag je zaključan i ne može se povezati sa novim uređajem.
--	--	--	---	--	--