


ENG

USER MANUAL TEMPO 38.123.71

Wireless Bluetooth Speaker



1. Power ON/OFF
2. LED charging indicator
3. Type-C USB Input

Specification

Pairing name: "TEMPO"
S/N Ratio: <6 dB
Speaker driver: 40 mm
Output power: 3 W
Wireless frequency: 2402 Hz – 2480 KHz
Battery capacity: 300 mAh
Bluetooth version: V 5.3
Charging time: 3 hours
Playing time: about 3 hours
Transmission distance: 10 m

Charging the speaker

A full charge takes approximately 3 hours and plays continuously for approximately 3 hours at 70% volume.

Connect the speaker to recharge using the cable provided. When the LED indicator is RED, the speaker is charging. The LED indicator goes off when the device is fully charged.

How to use

If you want to pair your mobile device with the speaker, please make sure the BT mode on your device is switched on. Switch the power on/off button on to pair the device. After doing so the speaker will be visible in the BT devices overview of your device. Please select "TEMPO" to pair your mobile device with the speaker.


Precaution

1. Please enjoy music with an appropriate volume level, which will avoid potential damage to your hearing and sound system.
2. Please avoid exposure to rain, water droplets, avoid prolonged exposure to high temperatures, and a high humidity environment.
3. During use, please keep away from heat, high pressure, and prevent children from playing with this product.
4. When the music volume is becoming quieter or distorted, slow, silent, it may indicate that the lithium battery power is low and may need to be charged.
5. Do not drop or bump and/or apply heavy pressure to avoid damage to the product.
6. Please do not disassemble the product to avoid danger.
7. If the item is not used for a long period of time please turn off the power and unplug the charger power cable.

SRB

UPUTSTVO ZA UPOTREBU TEMPO 38.123.71

Bluetooth bežični zvučnik



1. Dugme za paljenje i gašenje
2. LED indikator napunjenosti baterije
3. Type-C USB ulaz

Specifikacije

Ime uparivanja: „TEMPO“
S/N odnos: <6 dB
Drajver zvučnika: 40 mm
Izlazna snaga: 3 W
Bežična frekvencija: 2402 Hz – 2480 KHz
Kapacitet baterije: 300 mAh
Bluetooth verzija: V 5.3
Vreme punjenja: 3 sata
Vreme rada: oko 3 sata
Udaljenost prenosa: 10 m

Punjenje zvučnika

Potpuno punjenje traje oko 3 sata i neprekidno se reprodukuje oko 3 sata pri 70% jačine zvuka.

Povežite zvučnik za punjenje pomoću priloženog kabla. Kada je LED indikator CRVENI, zvučnik se puni. LED indikator se gasi kada je uređaj potpuno napunjen.

Kako koristiti

Ako želite da uparite svoj mobilni uređaj sa zvučnikom, uverite se da je BT režim na vašem uređaju uključen. Uključite dugme za uključivanje/isključivanje da biste uparili uređaj. Nakon što to uradite, zvučnik će biti vidljiv u pregledu BT uređaja vašeg uređaja. Izaberite „TEMPO“ da biste uparili svoj mobilni uređaj sa zvučnikom.

Predostrožnosti

1. Uživajte u muzici sa odgovarajućim nivoom jačine zvuka, koji će izbeći potencijalno oštećenje Vašeg sluha i zvučnog sistema.
2. Izbegavajte izlaganje uređaja kiši, kapljicama vode, izbegavajte dugotrajno izlaganje visokim temperaturama i okruženju visoke vlažnosti.
3. Tokom upotrebe, držite uređaj dalje od toplote, visokog pritiska i sprečite decu da se igraju sa ovim proizvodom.
4. Kada jačina muzike postaje tiša ili izobličena, spora, nečujna, to može značiti da je litijumska baterija slaba i da je možda potrebno punjenje.
5. Nemojte ispuštati ili udarati i/ili vršiti jak pritisak, kako biste izbegli oštećenje proizvoda.
6. Molimo vas da ne rastavljate proizvod da biste izbegli opasnost.
7. Ako se predmet ne koristi duže vreme, isključite napajanje i izvucite kabl za napajanje punjača.