

USER MANUAL

Model:

DALTON 10PD 38.218

This is a useful emergency phone charger. You can use it to charge your digital devices anytime and anywhere.

- Switch part: Press the button to check the battery level. Double press the button to quickly turn off the indicator light.
- Battery status indicator: 4 battery status indicator lights + 1 fast charging indicator light. Each battery status indicator light indicates approximately 25% of battery charge.
- Power bank charging state: 25% 50% 75% 100% , in turn flashing, the white light flashes, full of each light, the white light is on, 100% full of, four lights are on.
- Power bank discharging state: The current power lamp is white and steady on. After every indicator is used up, the lamp will turn off until the power is exhausted.
- Power bank fast charging state: The green indicator light is on.
- Type-C cable: Select the appropriate charging cable to charge your mobile device,

PRODUCT SPECIFICATIONS:



- 1 Type-C Input&Output
- 2 Switch
- 3 25% indicator
- 4 100% indicator
- 5 Fast charge indicator
- 6 Built in Type-C cable

Capacity: 10000mAh 38.5Wh

Type-C Input: DC5V/3A,9V/2A,12V/1.5A

Type-C cable Input: DC5V/3A,9V/2A,12V/1.5A

Type-C Output: DC5V/3A,9V/2.22A,12V/1.67A

Type-C cable Output: DC5V/3A,9V/2.22A,12V/1.67A

Size: 105*67*18.7mm

Battery: Li-Polymer battery

Material: ABS

CHARGE THE POWER BANK

- You can use the Type-C cable that comes with the power bank. It can connect to the charger to charge the power bank.

ATTENTION

- This product is not waterproof. Please do not wet it or use it during heavy rain.
- If the product accidentally falls into the water, please use a clean cloth to absorb the water on the product's surface, and do not switch on the device immediately.
- Please do not throw the power bank into fire to avoid explosion.
- Do not use or store the power bank in a hot (over 50 degree Celsius), wet or corrosive environment.
- Please keep out of reach of children. Do not use leave product unattended whilst in use.
- Do not open the device – shock hazard.
- Check whether the power bank is suitable for your mobile phone or electronic equipment prior to use.
- If the power bank has not been used for a long time, the power of the built-in battery can be depleted. To solve this problem, charge the charger for 2-3 hours. When it has some power, the charger will function again.
- In order to avoid damaging the battery, please use it at least once in every 3 months.
- Do not use the mobile phone whilst the battery is being charged with the power bank and do not charge the power bank overnight.
- When connecting the power bank to the device, please use the charging cables and connectors provided from the authorized maker. The use of charging cables or connectors from unauthorized maker may cause severe or fatal injuries and property loss and damage to the product and the device.
- Power Bank is compatible with Apple® Product USB cable/adaptor (Not Included)
- Do not leave the power bank operating in airtight space under sunshine, may cause the maximum operating temperature to be exceeded.
- Keep the power bank idle when recharging, do not keep charging other device and recharging power bank at the same time.

UPUTSTVO

Model:

DALTON 10PD 38.218

Ovo je praktičan prenosni punjač za telefon u hitnim situacijama. Možete ga koristiti za punjenje svojih digitalnih uređaja bilo kada i bilo gde.

- Taster za upravljanje: Pritisnite dugme da proverite nivo napunjenosti baterije. Dvostrukim pritiskom brzo isključujete indikatorsko svetlo.
- Indikator statusa baterije: 4 lampice za status baterije + 1 lampica za brzo punjenje. Svaka lampica statusa baterije označava približno 25% kapaciteta.
- Status punjenja power bank-a: 25% / 50% / 75% / 100% – lampice se naizmenično pale i trepere; belo svetlo treperi. Kada je potpuno napunjen, sve lampice svetle stalno, a belo svetlo je uključeno. Pri 100% napunjenosti sve četiri lampice su uključene.
- Status pražnjenja power bank-a: Trenutna lampica napajanja svetli belom bojom bez treperenja. Kako se kapacitet troši, lampice se redom gase, a kada se baterija potpuno isprazni, sve lampice se isključuju.
- Režim brzog punjenja: Zelena indikatorska lampica je uključena.
- Type-C kabal: Izaberite odgovarajući kabal za punjenje svog mobilnog uređaja.

SPECIFIKACIJE PROIZVODA



- 1 Type-C ulaz/izlaz
- 2 Dugme
- 3 Indikator 25%
- 4 Indikator 100%
- 5 Indikator brzog punjenja
- 6 Ugrađen Type-C kabal

Kapacitet: 10000mAh 38,5Wh

Type-C ulaz: DC5V/3A,9V/2A,12V/1,5A

Type-C kabal (ulaz): DC5V/3A,9V/2A,12V/1,5A

Type-C izlaz: DC5V/3A,9V/2,22A,12V/1,67A

Type-C kabal (izlaz): DC5V/3A,9V/2,22A,12V/1,67A

Dimenzije: 105*67*18,7mm

Baterija: Li-Polymer battery

Materijal: ABS

PUNJENJE POWER BANK-A

- Možete koristiti Type-C kabal koji dolazi uz power bank. Njime možete povezati punjač i napuniti power bank.

UPOZORENJE

- Ovaj proizvod nije vodootporan. Nemojte ga kvasiti niti koristiti tokom jakе kiše.
- Ako proizvod slučajno upadne u vodu, upotrebite čistu krpu da upijete vodu sa površine proizvoda i nemojte odmah uključivati uređaj.
- Ne bacajte power bank u vatru kako biste izbegli opasnost od eksplozije.
- Ne koristite niti skladištite power bank u vrućem (preko 50 °C), vlažnom ili korozivnom okruženju.
- Držite proizvod van domašaja dece. Ne ostavljajte proizvod bez nadzora dok je u upotrebi.
- Ne otvarajte uređaj – postoji opasnost od strujnog udara.
- Pre upotrebe proverite da li je power bank kompatibilan sa vašim mobilnim telefonom ili elektronskim uređajem.
- Ako power bank nije korišćen duže vreme, ugrađena baterija se može potpuno isprazniti. Da biste rešili ovaj problem, puniti uređaj 2–3 sata. Kada dobije određeni nivo napunjenosti, ponovo će normalno raditi.
- Kako biste izbegli oštećenje baterije, koristite uređaj najmanje jednom u svaka 3 meseca.
- Ne koristite mobilni telefon dok se puni pomoću power bank-a i ne ostavljajte power bank na punjenju preko noći.
- Prilikom povezivanja power bank-a sa uređajem, koristite isključivo kablove i konektore koje obezbeđuje ovlašćeni proizvođač.
- Upotreba kablova ili konektora neovlašćenih proizvođača može dovesti do ozbiljnih ili smrtonosnih povreda, materijalne štete, kao i oštećenja proizvoda i uređaja.
- Power bank je kompatibilan sa Apple® USB kablom/adapterom (nije uključen u pakovanje).
- Ne ostavljajte power bank da radi u zatvorenom, neprovetranom prostoru na suncu, jer može doći do prekoračenja maksimalne radne temperature.
- Tokom punjenja power bank-a, nemojte istovremeno puniti druge uređaje – ostavite power bank u stanju mirovanja dok se puni.