

ZAPPA WIRELESS HEADSET

1.

Long press for 3 seconds to switch the machine. Double-tap to skip to the next track; triple-tap to return to the previous track; a short press activates the voice assistant.

2. Encoder button

Turn clockwise to increase volume, counterclockwise to decrease volume. Press the middle button briefly to play or pause, hold it to connect or disconnect Bluetooth. Double-click to answer a call, press briefly to answer an incoming call, hold to reject an incoming call, and press briefly during a call to hang up.

Indicator light:

Wireless mode: red and blue light flash in pairing mode, and blue light flash slowly after successful pairing. Charging mode: the red light will be on long when charging, and the red light will be off after charging.

Wireless Operation Instructions:

Press the  key to power on.

Red and blue light flash, product into the pairing mode.

Search this wireless product with mobile phone, product BT name is ZAPPA

When the wireless connection is successful, the blue light flashes slowly.

Open the mobile phone music player to play music, the product can control the wireless music up and down, play pause and call answer, redial and other functions.

LINE External Audio Input Operation Instructions:

When the product is powering on, insert the audio cable into AUXLINEIN mode. Support mobile phone /MP4/ MP3/CD/ laptop and other external audio input.

Functional parameters:

USB charging: DC 5V IN

Wireless frequency: 2,402-2,480 GHz

Wireless distance: 10 m

Frequency response: 20 HZ-20 khz

Signal to noise ratio: 88 DB

Charging time: 2 hours

ZAPPA BEŽIČNE SLUŠALICE

1. ☺

Dugim pritiskom (3 sekunde) uključujete/isključujete uređaj. Dvostrukim dodirrom prelazite na sledeću pesmu; trostrukim dodirrom se vraćate na prethodnu pesmu. Kratkim pritiskom se aktivira glasovni asistent.

2. Točkić (Encoder dugme)

Rotirajte udesno (u smeru kazaljke na satu) da pojačate zvuk. Rotirajte ulevo da smanjite zvuk. Kratkim pritiskom sredine dugmeta: puštanje/pauza. Dugim pritiskom: povezivanje ili prekidanje Bluetooth veze. Dvostrukim klikom: odgovor na poziv. Kratkim pritiskom: odgovor na dolazni poziv. Dugim pritiskom: odbijanje poziva. Tokom razgovora, kratkim pritiskom prekidate vezu.

Indikatorska lampica

Bežični režim: crvena i plava lampica trepću u režimu uparivanja; nakon uspešnog uparivanja, plava lampica trepće sporo. Režim punjenja: crvena lampica svetli neprekidno dok se puni; gasi se nakon punjenja.

Uputstvo za bežičnu upotrebu:

Pritisnite dugme ☺ da uključite uređaj.

Crvena i plava lampica trepću – uređaj je u režimu uparivanja.

Na mobilnom telefonu pronađite bežični uređaj ZAPPA i povežite se.

Kada je veza uspešno uspostavljena, plava lampica trepće sporo.

Otvorite muzički plejer na telefonu — uređaj omogućava sledeće funkcije: puštanje/pauza, preskakanje pesama, odgovaranje na pozive, ponovno biranje i druge funkcije.

Uputstvo za spoljni audio ulaz (LINE IN):

Kada je uređaj uključen, priključite audio kabl u AUX LINE IN režim. Podržava mobilne telefone, MP4/MP3 plejere, CD plejere, laptopove i druge spoljne audio izvore.

Funkcionalni parametri:

USB punjenje: DC 5V

Bežična frekvencija: 2.402 – 2.480 GHz

Dolet bežične veze: 10 metara

Frekventni opseg: 20 Hz – 20 kHz

Odnos signal/šum: 88 dB

Vreme punjenja: 2 sata