


FRONT

USER MANUAL

PODCAST 38.116.10




It is recommended to read this user manual carefully and keep it for future reference.

Contents:

1(One) Speaker 228*174.5*81mm
1(One) USB-A to Type C PVC Charging Cable 80cm
1(One) Instruction Manual

Product Specification:

Speaker Output: 5W
Size: Speaker 228*174.5*81mm
Input: 5V 1A
Accessory: USB-A to USB-C Charging Cable (80cm)
Material: ABS + Acrylic



BACK

How To Use:

How to charging: Connect the type-C charging cable to the power adaptor. Please use power adaptor in 5V or above to boost the speaker. Power on/off: Press and hold "⏻" to turn on / off the unit.

Connect to Bluetooth:

- Press "⏻" to connect Bluetooth mode.Press "⌂" to control different colors and fix specific color.
- Search for Bluetooth audio name "PODCAST" on your device when the LED indicator light flashes in blue.
- You will hear a prompt sound when it is successfully paired.
- The speaker will automatically turn off without connection after 5 minutes. To reconnect, you can turn on the speaker and it will automatically connect back to your device.

Bluetooth Music Playback:

- Press "⏻" once to play / pause the music.
- Press "⏮" once to play the previous song.
- Press and hold "⏮" to reduce the volume.
- Press "⏭" once to play the next song.
- Press and hold "⏭" to increase the volume.

⚠ WARNING:

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.

- Do not pull the speaker charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the speaker.
- Do not drop, place heavy weight or allow heavy impact to the speaker.
- PCB of battery should not be crushed and twisted.
- Battery body should not be bended.
- Do not disassemble and Do not dispose of in fire.

RF warning statement:

- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.

Tips: Please do not turn the volume knob to the maximum level to prevent hearing damage and to prolong the service life of the system.

WARNING: "Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

Bluetooth®

The Bluetooth word mark and logos are owned by the Bluetooth SIG. All other trademarks appearing herein are the property of their respective owners.

¹Depends upon third party device compatibility.

