

KORISNIČKO UPUTSTVO  
RODEO 38.079.12



Preporučuje se pažljivo pročitati ovaj korisnički priručnik i sačuvati ga za buduću referencu

Pregled proizvoda:



Specifikacije:

Bluetooth verzija 5.4  
Napon punjenja: 5V==  
Litijska baterija 500mAh 3.7V  
Radno vreme: 2-3 sata  
Radna udaljenost: do 10 metara  
Frekvencija: 20Hz-20KHz  
Impedansa: 40 oma  
Izlazna snaga: 3W  
SNR: 80 Db

Funkcionisanje:

Dugi pritisak na ON/OFF dugme za uključivanje zvučnika. Iz Bluetooth menija vašeg uređaja, pretražite nove uređaje i izaberite "RODEO" za uparivanje.

Kada se uspešno upare, čućete zvučni signal obaveštenja i plava indikatorska lampica će ostati upaljena. Dugi pritisak na ON/OFF dugme za isključivanje zvučnika. Napomena: Jačina zvuka i sledeća/prethodna pesma moraju se kontrolisati sa vašeg mobilnog uređaja.

Punjenje uređaja:

Za punjenje koristite priloženi kabl. Povežite USB kabl sa računarom/naponskim adapterom. Priključite Type C kraj ovog kabla u USB C port vašeg uređaja.

Tokom punjenja, crvena indikatorska lampica će ostati upaljena. Kada je zvučnik potpuno napunjen, indikatorska lampica će se ugasi.

Rešavanje problema:

| Problem                                    | Rešenje                                                                                                                                                                                                              |
|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Nemogućnost uparivanja sa drugim uređajima | 1. Proverite da li je zvučnik i dalje u procesu pretrage ili ga isključite i ponovo uključite.<br>2. U blizini ima previše Bluetooth uređaja što može otežati povezivanje.<br>3. Isključite druge Bluetooth uređaje. |
| Zvuk je slab ili iskrivljen                | 4. Proverite jačinu zvuka na Bluetooth uređaju i podesite je na odgovarajući nivo.<br>5. Napunite bateriju.                                                                                                          |
| Povremeno se muzika zaustavlja             | 6. Proverite da li je prekoračen efektivni domet prenosa zvučnika ili da li postoji prepreka između zvučnika i drugih Bluetooth uređaja.                                                                             |

Upozorenja:

1. Ne izlažite ovaj proizvod kiši ili vlažnim uslovima.
2. Sprečite padanje ovog predmeta jer može prouzrokovati ozbiljnu štetu.
3. Ne rastavljajte, popravljajte ili modifikujte ovaj proizvod sami, kontaktirajte ovlašćenog stručnjaka.
4. Radi izbegavanja rizika, ne odlažite ovaj proizvod na neadekvatan način jer sadrži ugrađenu litijumsku bateriju.
5. Čistite zvučnik suvom krpom.
6. Ne postavljajte ovaj predmet blizu izvora toplote ili ga izlažite direktnom sunčevom svetlu.
7. Ne ubacujte metalne predmete u ovaj uređaj jer postoji rizik od kratkog spoja.
8. Čuvajte van domašaja dece.

  Ovaj simbol, kako na proizvodu tako i u korisničkom priručniku, označava da se na kraju električnog životnog veka uređaja treba reciklirati odvojeno od kućnog otpada. Postoje odgovarajući načini za odlaganje ovog materijala radi pravilnog recikliranja. Za više informacija, kontaktirajte lokalne vlasti.

## USER MANUAL

RODEO 38.079.12



It is recommended to read this user manual carefully and keep it for future reference

### Product Overview:



### Specifications:

Bluetooth Version 5.4  
Charging voltage: 5V===  
Lithium battery 500mAh 3.7V Working  
Time: 2-3h  
Operating distance: up to 10 meters  
Frequency: 20Hz-20KHz  
Impedance: 4ohms  
Power output:3W  
SNR: 80dB

### Operation:

Long press the ON/OFF button to power on the speaker.  
From the Bluetooth menu of your device, search for new devices and select "RODEO" to pair.

Once they are paired successfully, you will hear a notification sound and the blue indicator light will remain on.  
Long press the ON/OFF button to power off the speaker.  
Note: volume and next/previous track must be controlled from your mobile device.

### Charging:

Use the cable provided for charging. Connect the USB cable to computer/AC adapter. Connect the Type C end of this cable into the USB C port of your device.

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

### Troubleshooting:

| Fault                              | Solution                                                                                                                                                                                                                               |
|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unable to pair with other devices. | 1. Check whether the speaker is still in the process of search or switch it off and on again.<br>2. There are too many Bluetooth devices in the proximity that cause difficulty in connection.<br>3. Turn off other Bluetooth devices. |
| The sound is low or distorted.     | 4. Check the Bluetooth device volume and then adjust it to an appropriate level.<br>5. Recharge the battery.                                                                                                                           |
| Occasionally the music stops.      | 6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.                                                                                      |

### Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.