
ENG

# USER MANUAL

TULUM | 34.803



It is recommended to read this user manual carefully and keep it for future reference.

## Specifications:

- Input: 5V DC 2A
- Input port: Type-C
- The battery capacity: 3.000mAh
- Bluetooth specification: Bluetooth V6.0
- Wireless transmission range: ≤10 meters
- Bluetooth speaker power: 8W
- Frequency response: 20Hz-20kHz
- LED light: 4 levels brightness
- Touch control on top
- Lamp beads: 12 pieces
- Lighting power: 1.2W

## Operation:

- Long press the power button to power on speaker, from the bluetooth menu of your device, search for new devices and selected „ TULUM “ to pair, once they are paired successfully, you will hear a notification sound.
- Press the power button to play, or pause the music
- Long press the power button to power off the speaker
- Touch control on the top of lamp
- Short press to switch between 4 lighting modes
- Long press to achieve continuous dimming or brightening

## Charging:

- Use the cable provided for charging
- Connect the USB cable to computer / AC adapter
- Connect the USB-C end of this cable into the USB-C port of your device

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

## Troubleshooting:

| Fault | Solution |
|---|---|
| Unable to pair with other devices | 1. Check whether the speaker is still in the process of search or switch it off and on again.<br>2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. |
| The sound is low or distorted | 4. Check the Bluetooth device volume and then adjust it to an appropriate level.<br>5. Recharge the battery. |
| Occasionally the music stops | 6. Check whether the speaker effective transmission range is exceeded, or if there is an obstacle between the speaker and other Bluetooth devices. |

## Warnings:

1. Do not expose this product to rain or damp conditions.

2. Prevent this item from falling, as it could cause serious damage.

3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.

4. In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.

5. Clean the speaker with a dry cloth.

6. Do not place this item near sources of heat or expose to direct sunlight.


7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.

8. Keep out of reach of children.

**SRB**

# UPUTSTVO ZA UPOTREBU

TULUM | 34.803



Preporučuje se da pažljivo pročitate ovo korisničko uputstvo i sačuvate ga za buduću upotrebu.

## Specifikacije:

- Ulaz: 5V DC 2A
- Ulazni priključak: Type-C
- Kapacitet baterije: 3.000mAh
- Bluetooth verzija: Bluetooth V6.0
- Bežični domet: ≦ 10 metara
- Snaga Bluetooth zvučnika: 8W
- Frekvencijski odziv: 20Hz–20kHz
- Noćno svetlo: 4 nivoa osvetljenja
- Kontrola na dodir na vrhu uređaja
- LED diode: 12 komada
- Snaga osvetljenja: 1.2W

## Upravljanje uređajem:

- Dugo pritisnite dugme za uključivanje kako biste uključili zvučnik.
- Aktivirajte Bluetooth na telefonu i pronađite uređaj za povezivanje.
- Nakon uspešnog povezivanja čućete zvučno obaveštenje.
- Kratak pritisak omogućava reprodukciju ili pauziranje muzike.
- Dugim pritiskom uređaj se isključuje.

## Kontrola osvetljenja:

- Kontrola na dodir nalazi se na vrhu lampe.
- Kratak pritisak menja između 4 režima osvetljenja.
- Dug pritisak omogućava postepeno pojačavanje ili smanjivanje osvetljenja.

## Punjenje:

- Koristite priloženi kabl za punjenje.
- Povežite USB kabl sa računarom ili adapterom, a Type-C kraj sa uređajem.
- Tokom punjenja indikatorsko svetlo će biti uključeno.
- Kada je uređaj potpuno napunjen, indikatorsko svetlo će se ugasiti.

## Rešavanje problema:

| Problem | Rešenje |
|---|---|
| Nije moguće povezivanje sa drugim uređajima | Proverite da li je zvučnik uključen i u režimu za povezivanje.<br>Proverite da li postoje drugi Bluetooth uređaji koji ometaju signal. Isključite i ponovo uključite Bluetooth. |
| Zvuk je tih ili izobličen | Podesite jačinu zvuka i proverite stanje baterije. |
| Muzika povremeno prekida | Proverite udaljenost između uređaja i uklonite prepreke koje mogu ometati signal. |

## Upozorenja:

1. Ne izlažite proizvod kiši ili vlazi.
2. Pazite da uređaj ne padne jer može doći do ozbiljnog oštećenja.
3. Ne pokušavajte sami da rastavljate ili popravljate uređaj.
4. Koristite meku i suvu krpu za čišćenje.
5. Ne postavljajte uređaj blizu izvora toplote niti na direktno sunce.
6. Ne ubacujte metalne predmete u uređaj zbog opasnosti od kratkog spoja.
7. Držite uređaj van domašaja dece.